

# EQUIPMENT EXPRESS: Karaoke



- c. Align the pins and attach the XLR microphone cable to the MIC INPUT on the back of the speaker (see Photo 5).

## 2. Set Up the Speaker

The speaker power cable is located inside a zipped compartment near the pull handle of the duffel bag (see Photo 6).



- a. Align the pins and plug the power cable into the speaker (see Photo 7).
- b. Plug the power cable into an electrical outlet.
- c. Turn the speaker POWER on (see Photo 8).